

## PLANT TEMPERATURE CAMERA

The plant temperature is more important than the ambient temperature. If the camera is connected, the climate can be controlled based on the plant temperature. If the plant temperature is very high, the Maxi Controller will dim the lighting to keep the stomata open. In case of water shortage (e.g. due to a faulty pump) the lights are also dimmed or turned off to prevent crop damage.



Klik om naar het product: [PLANT TEMPERATURE CAMERA](#) te gaan.